

Remove the top. Remove the sides.



Use the forklift to lift the machine of the crate base from the broadside. Layout footpad strips flat side down. (only on some models)



Layout footpad strips flat side down.



Connect plugs.



Test machine.